

ERROR CODE LIST

Date:

09.03.2021

Version:

1

NUMBER	ERROR CODE	DESCRIPTION	CLASS
1	P 0118	Engine Coolant Temperature Sensor Circuit High / Open	B
2	P 0117	Engine Coolant Temperature Sensor Circuit Low	B
3	P 0116	Engine Coolant Temperature Sensor signal performance	B
4	P 1116	Engine Coolant Temperature Sensor signal out of range	B
5	P 0336	Crankshaft Position Sensor "A" Circuit Performance	B
6	P 0335	Crankshaft Position Sensor "A" Circuit	A
7	P 2301	Ignition Coil "A" Primary Control Circuit High	A
8	P 2300	Ignition Coil "A" Primary Control Circuit Low / Open	A
9	P 2304	Ignition Coil "B" Primary Control Circuit High	A
10	P 2303	Ignition Coil "B" Primary Control Circuit Low / Open	A
11	P 0123	Throttle Position Sensor/Switch "A" Circuit High	A
12	P 0122	Throttle Position Sensor/Switch "A" Circuit Low / Open	A
13	P 0459	Evaporative emission system purge control valve "A" Circuit High	A
14	P 0458	"Evaporative emission system purge control valve ""A"" Circuit Low / Open"	A
15	P 0232	Fuel Pump circuit short High	A
16	P 0231	Fuel Pump circuit short Low / Open	A
17	P 0601	Internal Control Module Memory Checksum Error	A
18	P 0262	Cylinder 1 Fuel Injector "A" Circuit High	A
19	P 0261	Cylinder 1 Fuel Injector "A" Circuit Low / Open	A
20	P 0265	Cylinder 2 Fuel Injector "B" Circuit High	A
21	P 0264	Cylinder 2 Fuel Injector "B" Circuit Low/Open	A
22	P 0108	Manifold Absolute Pressure Sensor Circuit High	A
23	P 0107	Manifold Absolute Pressure Sensor Circuit Low/Open	A
24	P 3106	Manifold Absolute Pressure Sensor rationality at low TPS	B
25	P 0105	Manifold Absolute Pressure Sensor signal stuck	B
26	P 0113	Intake Air Temperature Sensor Circuit High / Open	A
27	P 0112	Intake Air Temperature Sensor Circuit Low	A
28	P 0111	Intake Air Temperature Sensor signal stuck	B
29	P 0114	Intake Air Temperature Sensor Circuit Intermittent	B
30	P 0132	O2 Sensor Circuit High Voltage Bank 1 Sensor 1	B
31	P 0131	O2 Sensor Circuit Low Voltage Bank 1 Sensor 1 / Open	B
32	P 0138	O2 Sensor Circuit High Voltage Bank 2 Sensor 1	B
33	P 0137	O2 Sensor Circuit Low Voltage Bank 2 Sensor 1 / Open	B
34	P 2195	O2 Sensor Signal Lean at PE Bank 1 Sensor 1	B
35	P 2197	O2 Sensor Signal Lean at PE Bank 2 Sensor 1	B
36	P 014D	O2 Sensor Slow Response - Lean to Rich Bank 1 Sensor 1	E

Report number:

/

Created by:

Leisch

Affected VIN:

All

Controlled by:

Groll

Affected models:

Brixton Crossfire 500 / X

ERROR CODE LIST

ERROR CODE LIST

Date:

09.03.2021

Version:

1

NUMBER	ERROR CODE	DESCRIPTION	CLASS
37	P 014C	O2 Sensor Slow Response - Rich to Lean Bank 1 Sensor 1	E
38	P 014F	O2 Sensor Slow Response - Lean to Rich Bank 2 Sensor 1	E
39	P 014E	O2 Sensor Slow Response - Rich to Lean Bank 2 Sensor 1	E
40	P 0031	O2 Sensor Heater Control Circuit Low Bank 1 Sensor 1 / Open	A
41	P 0032	O2 Sensor Heater Control Circuit High Bank 1 Sensor 1	A
42	P 0037	O2 Sensor Heater Control Circuit Low Bank 2 Sensor 1 / Open	A
43	P 0038	O2 Sensor Heater Control Circuit High Bank 2 Sensor 1	A
44	P 00D1	O2 Sensor Heater current low Bank 1 Sensor 1	B
45	P 00D3	O2 Sensor Heater current low Bank 2 Sensor 1	B
46	P 0300	Random/Multiple Cylinder Misfire Detected	E
47	P 0301	Cylinder 1 Misfire Detected	E
48	P 0302	Cylinder 2 Misfire Detected	E
49	P 0563	System Voltage High	B
50	P 0562	System Voltage Low	B
51	P 0500	Vehicle Speed Sensor "A" Circuit	B
52	P 2257	Secondary Air Injection System Circuit Low	A
53	P 2258	Secondary Air Injection System Circuit High	A
54	P 0850	Park Neutral Switch fault	C
55	P 0650	MIL Circuit Fault	C
56	P 1693	Engine Speed circuit Low	C
57	P 1694	Engine Speed circuit High	C
58	P 0505	Idle air control system error	B

Report number:

/

Created by:

Leisch

Affected VIN:

All

Controlled by:

Groll

Affected models:

Brixton Crossfire 500 / X

ERROR CODE LIST